

Cloud Tops Tool on FltPlan Go

Figure 1

iPad 🗢		2:04 PM		⊀ \$ 30% █ +
(A)	Tools			
FitPlan.com				
Airports	PDC Service	Cloud Tops	О• w&в	
0		\sim		
Maps				
		注 - 2	4	
	eLogi	Book Cont	acts	
Navlogs				
\sim	Calculators			
Checklist			-	
	E 1283	I	150	
Binders	×=	٨	ISA	
	Numeric	C° <-> F°	Temperature	
Weather	[o]	Ja	Re.	
<u>_</u>	DA=X 1-()		AND -	
~	Density Alt.	Winds	Airport Winds	
Tracking				
(\land) 2.				
10015	-		-	
	Conve	rsions Equal	Time	
ScratchPad				
Downloads				
Settings				

Figure 2

Step 1

Launch the FltPlan Go app on your device

Step 2

From the **Dashboard** on the left side, tap on **Tools** *As shown in Figure 1

Step 3

From the **Tools** section, tap on **Cloud Tops** *As shown in Figure 1

Step 4

Line up the green line with the top of the cloud *As shown in Figure 2

Step 5

Place your finger over either **Lock** button *As shown in Figure 2

Step 6

Press down on the **Lock** button to lock the screen *As shown in Figure 3



Figure 3



Figure 5



Step 7

If satisfied with shot, swipe the **Lock** button to engage the lock *As shown in Figure 4

Step 8

Set the **Aircraft Altitude** *As shown in Figure 4

Step 9

Set your **Distance** in nautical miles to the clouds. By setting your distance, FltPlan Go will automatically compensate for the curvature of the Earth. *As shown in Figure 4

Figure 4



Note:

1. On the top of the screen, the center number is the height of the clouds above sea level (MSL). The number to the right of the center number is the height of the clouds above or below your aircraft. In the example to the left, the heights of the clouds are 38,300 ft MSL and -700 means the clouds are 700 feet below your aircraft *As shown in Figure 5

2. The distances will display green when flying above clouds, red if headed into or below clouds, and orange when close to clouds *As shown in Figure 5

3. The smaller numbers located above and below the altitude above the clouds give a margin of error of 0.1 of a degree in either direction (in the example to the left, the margins of error are 38,600 and 38,000 or 0.1 degree above and 0.1 degree below 38,300) *As shown in Figure 5

4. The angle is automatically calculated by your device's camera
*As shown in Figure 5